

## HOW DO I PAIR MY REMOTE WITH MY JETTER?



To pair a remote on a R50T, T30 or T80 there is a standard process. These systems use an 8 button, yellow, Autec A8 remote.

To pair this, the operator needs to be on the home screen of the machine, with the remote ready. Or PTO engaged of the T30's (no screen). Then turn the emergency stop of the remote to the off position, so that it is released. Then press the bottom right button of the 8 button remote 5 times to connect to the machine.



When doing this, the red symbol on the R50T will change to yellow - ready to connect. Or on a T80 the word "Remote Connector" will be displayed in the top right.



Then pressing the remote button, will change the "Remote" symbol to green, to say that the remote is now in charge.

Pressing the remote button again puts the control panel switches back in charge.

Finally, when the operator is done using the remote, they must press the emergency stop on the remote down, to turn off the remote, and save their battery.